




profi-air® classic plus – Montageanleitung/Mounting instructions




max. 225 m³/h



max. 360 m³/h




max. 450 m³/h




profi-air® classic plus – Montageanleitung/Mounting instructions

1

a




b




2


a




b




c




d



e




f




profi-air® classic plus – Montageanleitung/Mounting instructions


2




h



3




b




Optional:


15 m³/h



20 – 50 m³/h




20-25-30-35-40-45 m³/h



50 m³/h

profi-air® classic plus – Montageanleitung/Mounting instructions

4



5

